



Quick Start Guide



APT 3000 Series



This manual covers mainly the functional needs for powering and configuring 3100 A/D/G/H & 3200 A/G series transmitters, including the 3100 MP & 3100 L/ 3200 L sealed assemblies.

For full instructions on installation, configuration and other features/option sets available with these transmitters please read the full product manuals available under the download tab of www.autroltransmitters.com.

Additional instructional videos outlining programming and configuration functionalities can also be found on www.autroltransmitters.com. First time users are encouraged to make use of these support resources made available at no cost online.


For additional technical support or advanced troubleshooting please contact your nearest Autrol office or call 1-847-779-5000.

Getting Started


- Before installation check the model, specifications, and installation location for the transmitter. Install using proper engineering practice.
- Mount transmitter securely and stabilize any impulse piping.
- Follow the published pressure and temperature limits for ordered transmitter and options.
- For process temperatures $\geq 212^{\circ}\text{F}$, use of adequate impulse lines, capillaries (diaphragm seals), or cooling elements are recommended.
- Set Units, URL, and LRL (in menus 21, 22, and 23 respectively). See full menu tree at end of manual.
- After installation of a 3100 D/H/G or 3200 G always perform a Zero Trim (menu 11 - note this is not the same as Zeroing). Ensure applied process to transmitter is zero before attempting Zero Trim.
- Do not perform Zero Trim for 3100 A/ 3200 A (absolute) unless a true zero PV can be applied to these units. Instead a Zero Adjust (menu 12) is recommended.
- Zero Adjust is also recommended for 3100/ 3200 L (tank level application) to compensate for tank nozzle offsets.

Functional Block/Sensor Part Diagram


APT 3100




APT 3200




APT 3100 Dimensional Drawing




APT 3100 Exploded View




APT 3100 MP Dimensional Drawing




APT 3100 MP Exploded View



APT 3200 Dimensional Drawing





APT 3200 Exploded View



LCD Screen

The 5 digit LCD screen shows:

- Up to 5 digits of measured value
- Error code
- Units (Normal and Engineering)
- Menu and Menu Option
- Indication of being in Normal or Engineering mode
- Indication of output being Linear or Square Root
- Indication of performing a Loop Test
- Indication of being in Multi-Drop mode



LCD Screen Rotation

Unscrewing the two screws on either side of the LCD screen allows for the screen to be rotated 90° clockwise or counterclockwise.



LCD Screen Display Error Codes

| Message | Description | Remarks |
|---------------|--|--------------------|
| ADJ-U | Set value outside of upper limits during Zero Adj function | Check Limits |
| ADJ-L | Set value outside of lower limits during Zero Adj function | Check Limits |
| ZERO | Initial message when activating Zero button | Apply Zero Input |
| SPAN | Initial message when activating Span button | Apply Span Input |
| BT-ERR | Button Input Sequence Error | Check Key Sequence |
| P-LOCK | Write Protect Lock On | Check Jumper |
| ZT-ERR | Setting Limit (10%) Error when performing Zero Trim | Redo Zero Trim |
| -TR- | Zero Trim done | Successful Trim |
| ZR-ERR | Set value outside of upper limits during Zero Trim | Check Limits |
| SP-ERR | Set value outside of upper limits during Span Trim | Check Limits |
| -ZR- | Zero button function done | Apply Zero PV |
| -SP- | Span button function done | Apply Span PV |
| -ZA- | Zero Adjustment done | Z-Adj Accepted |
| -DONE- | Setting Done using button | Changes Accepted |
| RNGOVR | Over Range | Check Limits |
| LCD_OV | Over Range for LCD display | Check Limits |

| Message | Description | Remarks |
|----------------|---|----------------------|
| SCD--ER | Sensor Code Error | Check Sensor |
| F-RST | Flash Setting Data Reset | Reboot |
| F-LOCK | While Flash Setting Data Reset, Protect Locked | Write Protection On |
| F-FAIL | Flash Setting Data Reset Failure | Initialize Failed |
| -FR- | Flash Reset Done | Initialize Completed |
| A-RST | Analog EEPROM Initializing Start | Initialize Initiated |
| A-STOR | Analog EEPROM Whole Write | Write Initiated |
| A-FAIL | Analog EEPROM Whole Write Failure | Write Fail |
| -AC- | Analog EEPROM Whole Write Done | Write Completed |
| S-FL | Sensor Failure | Check Sensor Input |
| S-OP | Sensor PV exceeds MWP | Check Limits |
| AEP-RF | Check Sum Error in EEPROM during Read Sequence | Reboot |
| AEP-WF | Check Sum Error in EEPROM during Write Sequence | Reboot |
| TS-FL | Temperature Sensor Failure | Replace |
| EOSC | Sensor Element Defective | Replace |
| FAVE | Flash Access Violation | Reboot |

Fail-Mode


AUTROL® Smart Pressure Transmitters automatically perform real time self-diagnostic routines and display any error codes on the local LCD (M1 option if ordered) that can be used for troubleshooting. In addition to this, the self-diagnostic routines are also designed to drive transmitter current output outside of the normal saturation values in case a fault mode is detected. The transmitter will drive its current 4-20mA output low (down) or high (up) based on the position of the failure mode alarm jumper (or DIP switch) configured in line with NAMUR requirements.

| Level | 4-20mA Saturation | 4-20mA Alarm |
|----------|-------------------|--------------|
| Low/Down | 3.9 mA | ≤ 3.75 mA |
| High/Up | 20.8 mA | ≥ 21.75 mA |

| Selected Fail Mode | Jumper status on LCD and DIP Switch (2) on CPU Module | | DIP Switch (2) setting on CPU Module |
|--------------------|---|------------|--------------------------------------|
| | CPU Module | LCD Module | CPU Module |
| Fail Down | Down | D | Down |
| Fail Up | Down | U | Up |
| | Up | U or D | |


18

Fail Mode Selection Jumper Switch on LCD Module




*For Blind units using DIP switch on MCU board .

DIP Switch Settings




DIP (2): Fail Mode (Alarm)
Down: Fail Low
Up: Fail High



19

Power Supply Load Limitations



11.9-45 Volts DC is recommended for powering the transmitter. The external power supply ripple noise should not be higher than 2%. When calculating loop resistance please include resistance of all devices added in the loop. For intrinsic safety applications when using an Intrinsic Safety Barrier, please also include the resistance of the barrier into the max loop resistance calculations.

$$\text{Max. Loop Resistance } [\Omega] = (E - 11.9) [\text{Vdc}] / 0.022 [\text{mA}]$$

Note for Standard 4-20mA output units, operating at 11.9V is possible only with Zero load connected to transmitter analog output. HART is not supported at this low of supply voltage input.


17.5V is recommended as minimum drop across the transmitter for both HART and 250 Ohm loop resistance (loads).

24V +/- 30% is the typically recommended operating range for standard 4-20mA(HART) transmitters.

For 12V and lower please refer to our 3100/3200 LV (low voltage, 1-5V output units)

Connection Diagram

of Signal, Power and HTT for Standard Model Transmitters




1. HHT (HART Communicator) or PC Configurator may be connected at any terminal point in the signal loop
2. HART Communication requires a loop resistance between 250 and 550 Ohm at 24 Vdc
3. Power Supply
 - Voltage Range: 12 to 45 Vdc
 - Voltage Rating: 24 Vdc ± 30%



Connection Diagram

For Low Voltage Transmitters



Input Power Supply Connection
and Hang Jack Connection




DC Power


Minimum operating input of 9V (with no loading), recommended 12V (48V maximum).

Connection Diagram

For 3100F (Pulse Out/ Flow Transmitters)



Pulse Output Hook Up



Pulse Specification

- Scaled Pulse: A single pulse is output for a specified flow amount
- Pulse Width: 10ms, 50ms, 100ms selectable
- Duty Cycle: 49 Pulse/Second maximum
- Output Type: Open Collector, 30V, 500mA maximum

Minimum operating 17.5V (with no loading), Recommended 24V minimum for pulse and 4-20mA 2-wire loops.



Housing Rotation

Unscrewing the housing rotation screws in the front and back of the transmitter allow the housing to be rotated 90° counterclockwise.

360° rotation possible, however please take care that the sensor cable (inside neck) is not pinched or damaged during re-orientation.




Lock Front/Rear Covers

Allen Screw provided on each side of Front and Rear Cover allows for locking the covers for tamper proofing.




Grounding

Please provide for proper grounding (earth ground) at designated points (external or internal).



Vent/Drain Plugs




Optional with F1 or F2 Code

Standard with Bleed

Fully Functioning Push Buttons

To access the magnetic push buttons loosen one of the screws holding down the nameplate on the top of the transmitter. Turn the nameplate out of the way; underneath are two push buttons labeled Zero and Span. These magnetic push buttons are fully functioning (see menu tree in following pages).



Re-Ranging and Applying External PV

- Press Zero (5 sec)
 - When display shows “-ZR-” release the button
 - Apply PV corresponding to desired LRV (4mA) setting
 - Press Zero again. Display will show -Z or -ZE if error occurs.
- To adjust SPAN press SPAN button (5 sec)
 - When display shows “-SP-” release the button
 - Apply PV corresponding to desired URV (20mA) setting



*IMPORTANT

It is highly recommended to use a PV source that is at least +/- 0.005% accurate to avoid adding negative bias to factory calibration. If accurate PV source is not available please use push button menu 2.2 & 2.3 to re-range accurately without need of applying an external PV source.

Local Push Button Menu (Ver7.x and Higher)

Menu Functions of the push buttons are controlled by the firmware version of the transmitter.


Please check the specific firmware version listed on the neck tag of the transmitter (under LCD screen), as this may limit the available features.


As new features are continuously added please check with the most current manual online for any specific updates on new firmware's and functionality included.

All available menus are divided into 4 primary sections

- 1(TRIM) - for trims, loop test etc.
- 2(SETUP) - for user configuration (units, range settings, output, damping etc.)
- 3(LCD) - for display resolution, multi-parameter display, engineering mode
- 4(Device) - for reset, password lock, Hart Device ID, etc.

Menu Tree for Version 6.x and Lower







*Continued on next page

*

Version 7.x and Higher



*Continued on next page



1. Save/Cancel

After making a change or selection, a flashing SAVE will appear that requires a response. The Zero button will toggle between the SAVE/CANCEL options and the Span button will select and execute the flashing action. Both cancel ling and saving return the user to the previous menu.

2. Enter Value

- The first selected digit will be flashing
- Zero button increases the value
- Span button decreases the value
- Press both buttons to save a value and move onto the next digit
- After the last digit has been entered press both buttons to save the entire value

3. Select

Use the Zero button to scroll through options when making selections.


4. Display Options

- NOR_PV
- NOR_%
- NOR_mA
- ENG_RO
- ENG_PV
- NOR_RO


5. Once Engineering parameters have been set, engineering mode must be enabled in menu 311 for the LCD screen to show these parameters for local indication.

Sub Menus

Numeric Entry Sub Menu



Alpha - Numeric Entry Sub Menu



Headquarters

Autrol Corporation Of America

796 Tek Drive,

Crystal Lake, IL 60014, USA

Phone: +1 847-857-6062 | +1 847-779-5000

Fax: +1 847-655-6062

Sales: sales@autrolcorp.com

Support: tasc@autrolcorp.com

Website: www.autroltransmitters.com

Business Units

Autrol US LLC (AUS)

P.O. Box 61125

Midland, TX 79711, USA

Autrol Canada Inc.

102-15910 Frazer Highway, Suite 803

Surrey B.C V4N0X9, Canada

America Autrol SA DE CV

Pozo Rica 706, Col. Petrolera 89110

Tampico, Tam. Mexico

